

The microphone channels are also located on the left side of the D&R Webstation.

The Airlite is really a slightly bigger version of the Webstation so the microphone faders are also located on the left hand side (but there are three of them).

Step 2: Push the fader to the top

Each mic will have a corresponding fader. In this image the Mic 1 fader is 'open' so we would need to talk into Mic 1. Usually this will be on the left hand side to match the fader.



Step 3: Talk into the mic

If your microphone looks like the image to the right then it is important to make sure you are facing the logo as this indicates you are talking into the front of the microphone. Get nice and close and try not to move your head around too much when you are talking.

If your microphones look more like ice-cream cones then you need to make sure you are talking into the end of them. Once you are happy you are speaking into the correct part of the microphone it is time to check the levels.



Step 4: Check the levels